

AMERICAN CAR CRAFT

18701 Old Shady Hill Rd. Spring Hill, Fl. 34610

Phone: 727 857-1151 Fax: 727 856-0273

www.americancarcraft.com

C5 Exhaust Port Filler Panel

PART#C500 #C500LC #C500LZ #C500LA

INSTALLATION INSTRUCTIONS

NOTE: Your new exhaust port filler panel is designed to fit over the factory exhaust pipes. The large section of your new filler panel ships to you completely flat. In order to achieve a nice gapless fit it will be necessary to curve this panel slightly. This can be done very easily by following these simple instructions.

YOUR PANEL COMES WITH A PROTECTIVE LINER DO NOT REMOVE LINER UNTIL INSTALLATION IS COMPLETE.

- 1. Before inserting the large section over the factory exhaust gently curve the panel at the two outer corners. SEE ATTACHED PHOTOS.**
- 2. Carefully insert the large section over the top of the exhaust until it hits the face of the trunk area. With some force pull down the lower section in between the exhaust so that it lines up with the bottom of the trunk area. At this time also line the left and right corners of the panel so that it lines up with the bottom of the urethane bumper. SEE ATTACHED PHOTOS.**
- 3. This is a good time to check and see if there are any remaining gaps between the panel and the bumper. If you do have any gaps they can be eliminated by gently pulling down on either corner while pressing at the gap. SEE ATTACHED PHOTOS. This should allow you to work out any gaps between the bumper and the panel.**
- 4. Once you are satisfied with the overall fit you are ready to install the smaller locking panel, this procedure is outlined in step 5.**
- 5. Before inserting the small panel it will be necessary to check how it lines up with the larger panel. You can do this by placing the smaller panel in front and over the face at the bottom of the large section. SEE ATTACHED PHOTO. If the do not meet properly you can gently bend the smaller section until you achieve the correct fit.**

- 6. Now you are ready to permanently install your panel. The easiest way to do this is by lying on your back and sliding yourself under the car. Remove the red liner from the double face tape of the small section. Using your thumb and forefingers pull the larger section away from the trunk wall and insert the smaller section behind it being sure that they two sections line up at the sides and at the bottom. Press firmly to set. SEE ATTACHED PHOTOS.**

- 7. Once the two pieces are attached to each other line up the entire panel to your satisfaction and install the two self tapping screws provided. This can be done with a screwdriver or a powered screw gun. SEE ATTACHED PHOTOS.**

- 8. Remove protective liner.**

If any questions occur during installation please contact American Car Craft at 727 857-1151.

NOTE: Care must be taken when cleaning your new panel. It is a good idea to lightly dust your cover with a California duster in order to prevent any particles from scratching it. Then spray and wipe with a good quality glass cleaner and lint free paper towels.

Thank you and enjoy your new purchase!