

May/ 2005 - This product is protected by a U.S.Patent pending - May/ 2005

Installation Directions

Rear Spoiler Accent ILLUSION Graphic

*You are about to install a vinyl graphic. The finished result will be a direct representation of an Accent spoiler shadow of your car. **The finished result will only be as good as your installation, take the time and patience required to install the product correctly. You will be glad you did.***

It is strongly suggested that you wash and clean the area to be installed thoroughly so that it is free from any dirt, bugs, etc. If not, they may show through the vinyl.

You will need some simple tools to install this graphic. It is suggested that you have them ready to use before you start the installation.

- 1- soapy water in a spray bottle (Windex works well too)*
- 2- Decal squeegee application tool (a credit card will work too)*
- 3- A dry soft terrycloth rag (a hand towel works fine)*
- 4- Scissors or single edge razor knife*
- 5- (optional) Hair dryer*

*Before you can install the graphics, if not done so already, you must cut them out of their sheet. Use your scissors or razor blade and cut them out leaving about ¼ each of space around them. **DO NOT cut the graphic.** Place them aside until you need them. It is recommended that you are in a covered area (like a garage) or an area where there is no breeze.*

*Now, there is a left and right graphic. When ready to apply the graphic, peel off the **PAPER** backing and **leave the clear covering and graphic in tact.** Now, the easiest way to apply the graphic is to spray a **light** coating of soapy water to the area to be installed. You want to follow the natural line in the spoiler about ½ inch from the top. You want to measure about ½ inch, or if you're comfortable, eye the distance from the third brake light and apply the left graphic maintaining the top edge of graphic with the natural line in the spoiler. OK, now you may want to just hold up the **RIGHT** graphics and line up with the **LEFT**, again maintaining the distance from the brake light on the **RIGHT** is the same as the **LEFT**. Once you are comfortable with each side being symmetric and even you may apply and start to use*

your squeegee tool to smooth out any moisture air bubbles. Be sure not allow the graphic to shift. Gently work the tool towards the edge of the graphic continuing to push the air and moisture away from the graphic. Continue until you have as few small bubbles left as possible.

*You can use a hair dryer or heat gun **from a distance and on LOW** to accelerate the drying process. When everything is in place carefully remove the clear covering making sure the graphic stays in place. The natural heat from the sun will take care of any remaining imperfections over the next few days.*

OK, you're done! Stand back and admire your work.

****** *This graphic is a Quality Avery vinyl product and has an excellent adhesive that will last for a long time still retaining a removable option. Do NOT hasten that option by using a power washer with high pressure. Wash your car as usual with your favorite car wash and normal hose pressure.*

****** *You may use a wax or use a protectant type product on this product but it is NOT recommended for extended use.*