



1501 Industrial Way North, Toms River, NJ 08755
Phone: (732) 349-2109 • Fax: (732) 244-0867

PART #21116

2005 C6 Corvette SLP Blackwing Air Intake System

PACKING LIST *Before installation, use this check list to make sure all necessary parts have been included.*

ITEM	QTY	CHECK	PART NUMBER	DESCRIPTION
1.	1	<input type="checkbox"/>	21110	Filter, Blackwing
2.	1	<input type="checkbox"/>	200015636	Intake Tube
3.	1	<input type="checkbox"/>	200097051P	Bracket, C6 Intake, Coated
4.	2	<input type="checkbox"/>	25176248	Grommets, Blackwing, C6 Intake
5.	2	<input type="checkbox"/>	940069797	Binding Barrel, 1/4-20 X 5/16"
6.	2	<input type="checkbox"/>	940706795	Screw, 1/4-20X3/8" Flat Head
7.	2	<input type="checkbox"/>	940020600	Bolt, Hex Head, M6X1.00X20
8.	2	<input type="checkbox"/>	940020601	Washer, Flat, M6
9.	2	<input type="checkbox"/>	050497600	Label, SLP, White
10.	1	<input type="checkbox"/>	*****	Instructions

Warning: SLP recommends allowing the vehicle to cool (not running) for five hours before beginning the installation. SLP recommends wearing safety glasses for the complete installation.

INSTALLATION INSTRUCTIONS

1. Remove the stock air boxes and duct from the inlet of the MAF sensor forward.

2. Install the 2 Binding Barrels with flat head screws onto the supplied flat black bracket as shown in the photo 1 below.



Photo 1

3. Next install the mounting plate with binding barrels as shown in photo 2 below with the supplied 6mm screws and washers.



Photo 2

4. Next install the rubber grommets supplied into the SLP Blackwing filter as shown in photo 3 below.



Photo 3

5. Next install the new SLP Blackwing filter onto the mounting plate as shown in photo 4 below. If needed spray the rubber grommets with WD-40 so that they can slide onto the binding barrels without a struggle.



Photo 4

6. Next install the new SLP Intake Duct into the filter coupler then onto the MAF, using the stock worm drive clamp from the inlet side of the MAF. See photo 5 below.



Photo 5

7. Make sure all clamps are tight and the SLP intake duct is secured to the radiator guard with the stock grommets.

8. The installation is now complete. If any technical help is needed please call SLP at 732-349-2109.