

CAMARO 6pc HEADLIGHT RESTYLING KIT

PART #102016

PART INCLUDED:

- 1-Adhesive Promoter Pack
- 1-Adhesive Promoter Tube
- 2-Headlight Laminates
- 2-Headlight Stainless Trim Rings
- 2-Chrome Vinyl Trim Sections

This new kit has been designed to enhance the front of your new Camaro without having to spend a fortune. The kit will totally change the character of the front of the car by treating the headlights and grille with a simple but well thought out arrangement of components. A classy upgrade to the grille area that will impress you for years and it is simple to install.

1. The first step is to thoroughly scrub clean the headlight and center grille rail with alcohol to remove any and all road grime dirt and wax.
2. You have been provided with a small packet of adhesive promoter. Apply the promoter directly to the center horizontal rail of the factory grille and also around the perimeter edges of the headlight. Save some of this promoter fluid for later.
3. Now that the areas are prepared the first part to install is the headlight laminate. Before you try to stick anything, set the laminate in place over the headlight to get acquainted with its position. It is important for you to position the laminate so that you will have an even overlap all around the light. Try to look at this position in such a way as to allow you to be able to set it exactly in the same spot once you are ready to permanently stick the laminate.
4. Now that you are ready peel the release liner from the back of the laminate completely. Bring the laminate very close to the light but do not allow it to touch just yet. Align the laminate to a good position and then set one edge to the light holding the bulk of the laminate away. Press the laminate to the headlight using your thumb sliding it from side to side as you press out any air bubbles. Try not to stretch the laminate as this will cause wrinkles. Just spread it out onto the light as evenly as possible. Once you get started doing this you will see that it is actually very easy to spread and that the laminate will conform very nicely to the light. It will also allow you to roll it over the edges of the headlight leaving you with a very nice lamination.

5. The next step will be to install the stainless trim ring to the headlight. It is important to understand that this ring **must be manually contoured** to the headlight. If you try to install this part without reshaping it perfectly and allow the adhesive to hold the contour **IT WILL LIFT!**. So take a little time to gently shape the ring so that it matches to the headlight contour perfectly. Since metal will generally not bend itself out of shape so taking this extra time will insure a nice long lasting bond. Once you have achieved this simply peel the red release liner from the back of the part and then carefully manipulate it in place pressing firmly along the ring to set it to the headlight. Remove the protective liner.
6. The last step will be to set the black chrome trim to the center horizontal rail of the factory grille. You will notice that each of the two pieces is precut to fit to the emblem at the center of the grille. Match the correct trim to the emblem and then peel the red release liner from the back of the trim completely and careful set it nice and straight directly to the grille. A properly set trim should but up nice and tight to the emblem on one end and then tuck up against or just under the headlight trim ring on the other end. This will depend on how your headlights are set in place. Although it should not be necessary you may need to cut any excess trim as you set the end. A common scissor will work fine. Press firmly along the entire length to set and finish the installation.

