

2010+ Camaro T4 / T5 Side Rockers
Will Fit Camaro V6, V8, SS, RS, LT, LS 2010 +
Pn 33-4-027

Packing List

- Driver's Side T4 / T5 Side Rocker Panel
 - Passenger T4 / T5 Side Rocker Panel
 - 18 - Clips
 - 16 - U Nuts
 - 16 - Mounting Screws
 - Instructions
 - Proudly Packaged by
-



2010+ Camaro T4 / T5 Side Rockers
Will Fit Camaro V6, V8, SS, RS, LT, LS 2010 +
Pn 33-4-027

1. Observe proper precautions and safety procedures while performing the following.
2. Raise vehicle to a comfortable working height.



3. Clean the painted surface of the original rocker on the car. Ensure the underside portion is free of debris and residue. Pay special attention to the rectangular features; shown circled below.



4. You may need help of an assistant to hold the ACS rocker panel onto the car's panel. Trial fit the panel to ensure the locators (rectangular features) fit snugly and tightly to car's surface.

5. You can use 3 A-spring clamps to hold the ACS rocker to the car's rocker panel. Double check it is properly located. Center the rocker front to back, ensuring the rectangular features circled in step 3 are nested.

2010+ Camaro T4 / T5 Side Rockers
Will Fit Camaro V6, V8, SS, RS, LT, LS 2010 +
Pn 33-4-027



Drilling the lower mounting holes

5. Using an 8 mm (5/16") drilling bit and using the ACS Rocker as a template score the car's rocker. **Do not drill through the surface.**



6. Remove the A clamps and ACS Rocker panel. Now you can drill the pre-scored holes from step 5. You can use a drill depth stopper, so you don't hit the undercarriage as you drill through the car's rocker panel. Keep in mind the panel thickness is only 1/8". Clean off any burrs.



7. Install the U Nuts by sliding them onto the car's rocker panel from the center of the car towards the outside.

