



2007-08 Chevy Tahoe, Suburban, Avalanche Z-71

Marque Mesh Tow Hooks

After

PART# 3706

Hardware

- 6 - 10-32 x 5/8" Bolts
- 6 - 10-32 Rubber Well Nuts



Place the marque mesh billet grille into the bumper opening and center. Check alignment around opening.



Using a 90° scribe mark mounting hole locations. You will be able to reach through one of the marque hole openings to mark locations.



After marking remove mesh grilles from opening. Drill using a 3/16" drill bit as a pilot hole then move to a 3/8" drill bit and drill again as shown. Repeat process for remaining attachment holes. We used a step drill bit, if this method is used take your time and drill to the 3/8" step, do not over drill the hole size.



Locate the supplied rubber well nuts (fig. b). Place the rubber well nuts in just drilled locations as shown. Push in place so that the top portion seats against plastic as shown.



Place the mesh grilles into opening and center. Attach using the supplied 10-32 x 5/8" bolts. The use of a ball end allen wrench will be necessary as shown above.

Completed Installation

For installation of billet grilles that require cutting of the stock shell, proper tools, knowledge and skill are needed. Carriage Works is not responsible for care & accuracy of the installation, only for Fit & Finish of its products. Use a qualified installer or contact original vendor for references to complete all instructions.

NOTE: Please adjust horizontal blades if irregular. This is the result of shipping and handling outside of Carriage Works control. Also Carriage Works Recommends applying a high quality automotive wax to maintain the original appearance.