



# AIRCHARGER


## INSTALLATION INSTRUCTIONS

63-1099  
PONTIAC  
GTO  
V8-5.7L

NOTE: This kit was not designed to fit vehicles with a body lift.

### TOOLS NEEDED:

Flat Blade Screwdriver  
10mm Wrench  
1/2" Wrench  
Ratchet  
Extension  
10mm Socket  
T-30 Torx Socket  
17mm Socket  
Pliers



### PARTS LIST:

Desc.	QTY.	Part #
A hose clamp, #64	1	08648
B silicone hose; 4.5" x 1.5"L	1	08755
C hose clamp; #60	1	08628
D intake tube (DY)	1	087125
E grommet, 1"od, 1/2"id, 1/2"thk	1	08064
F bracket	1	010061
G washer; 5/16"id x 5/8"od	2	08276
H bolt; m10-1.5x25mm L	1	07702
I bolt; m8-1.25 x 16mm hex	1	07844
J washer; 8mm wave	1	08239
K washer; 8mm flat, ss	1	08134
L hose clamp; #56	4	08620
M silicone hose; 3.5" x 2"L	2	08698
N heat shield	1	074026
O edge trim 33"L	1	102498
P bolt; 6mm-1.00 x 16mm, hex	2	07703
Q washer; 1/4"id x 5/8"od, flat	3	08275
R nut; 6mm nylock	1	07553
S insert; 5/16"-18x.600"odx 730"L	1	088002
T bolt; 5/16"-18 x 1"L, ss	1	07777
U bracket sm. C	1	010062
V washer; 1/4"lock	1	08198
W filter adapter #380	1	21512
X hose clamp #104	1	08697
Y filter charger	1	RF-1048

### TO START:

1. Turn the ignition OFF and disconnect the vehicle's negative battery cable.



2. Release the center pin on the five radiator cover clips. Then remove the clips from the radiator cover.



3. Lift up on the radiator cover and pull back to release from the retaining hook, then remove the cover from the vehicle.



4. Release the air temp. electrical connection clip, then disconnect the electrical connection.



5. Loosen the two intake tube hose clamps, then remove the intake tube from the vehicle.



6. Release the mass air sensor electrical connection clip, then disconnect the electrical connection.



7. Pull the coolant reservoir up and away from the inner fender to release it from the retaining studs.



8. Have an assistant hold the coolant reservoir up, lift up on the air box assembly to release it from the retaining studs. Then remove the air box from the vehicle.




9. Reinstall the coolant reservoir onto the mounting studs as shown.



10. Lift up and pull out the air deflector from behind the head light.



11. Remove the inner airbox mounting stud shown with a T-30 torx socket.



12. Install the tube bracket #010061 using the provided hardware.

NOTE: The 10mm mounting bolt threads into the threaded, unused hole in the cylinder next to coolant temperature sensor.




13. Install the silicone (08755) onto the throttle body and secure with the provided hose clamp.



14. Remove the air temperature sensor from the stock intake tube.




15. Install the provided rubber grommet into the K&N intake tube as shown.



16. Install the air temperature sensor from step #14 into the grommet in the K&N intake tube as shown.



17. Install the K&N intake tube onto the throttle body as shown and secure with the provided hose clamp, using the 8mm bolt provided. Secure the K&N intake tube onto the mounting bracket installed in step #12.



18. Install the provided edge trim onto the heatshield as shown.



19. Install the radiused filter adapter into the K&N filtercharger as shown. Secure with the provided hose clamp.



20. Install the provided silicone hose (08698) onto the filter adapter and secure with the provided hose clamp as shown.



21. Using a pair of pliers, loosen the spring clamp on the coolant reservoir hose. rotate the coolant hose 90 degrees down as shown. Then resecure with the stock clamp.  
**NOTE:** Make sure pressure is released from radiator cap before loosening spring clamp.



22. Set the heatshield assembly onto the inner fender, then set the filter charger assembly between the heatshield and fender as shown.




23. Secure the heatshield to the inner fender with the 6mm bolt provided.  
**NOTE:** Thread the 6mm bolt into the hole vacated in step #11.



24. Install the threaded insert into inner fender as shown.



25. Install the heatshield bracket (#010062) onto the heatshield and inner fender and secure with the provided hardware.



26. Loosen the hose clamp that secures the mass air sensor to the factory air box, then remove the mass air sensor from the factory air box.




27. Install the silicone hose (#08698) onto the intake tube side of the mass air sensor and secure with the provided hose clamp.

**NOTE:** There is an arrow on the side of the mass air sensor which shows direction of air flow through the sensor and points the intake tube side of the sensor.




28. Install the mass air sensor assembly onto the K&N intake tube and secure with the provided hose clamp.



29. Install the filter charger assembly onto the K&N intake tube and secure with the provided hose clamp.



30. Reconnect the mass air sensor electrical connection.



31. Reconnect the temperature sensor electrical connection.



32. Reinstall the radiator cover removed in step #3.



33. Reinstall the five radiator cover retaining clips removed in step #2.



34. Reconnect the vehicle's negative battery cable. Double check to make sure everything is tight and properly positioned before starting the vehicle.

36. It will be necessary for all Aircharger's to be checked periodically for realignment, clearance and tightening of all connections. Failure to follow the above instructions or proper maintenance may void warranty.

#### ROAD TESTING:

1. Start the engine with the transmission in neutral or park, and the parking brake engaged. Listen for air leaks or odd noises. For air leaks secure hoses and connections. For odd noises, find cause and repair before proceeding. This kit will function identically to the factory system except for being louder and much more responsive.
2. Test drive the vehicle. Listen for odd noises or rattles and fix as necessary.
3. If road test is fine, you can now enjoy the added power and performance from your kit.
4. K&N suggests checking the Filtercharger element periodically for excessive dirt build-up. When the element becomes covered in dirt (or once a year), service it according to the instructions on the Recharger service kit, part number 99-5050 or 99-5000.